


How to Apply the Vista[®] 464 TLSO




1



PREPARATION

Place the pull tabs 2 inches (5 cm) from the plastic in the back of the Vista 464 TLSO brace. Pull the ends of the brace away from each other ensuring that it is fully extended.

2



PLACEMENT & ADJUSTMENT

Center the back panel as low as possible. Slide abdominal panel and sternal pad sideways as needed to ensure brace and panel are at midline.


3



SHOULDER STRAPS

Attach underarm control straps to sternal pad as directed.


4



TIGHTENING

Slip your thumbs through the holes in the pull tabs. Pull away from your body. The left pull tab controls lower compression and the right pull tab controls the upper compression. Adjust the compression as needed. When tightened, secure the pull tabs to the loop in front of the brace.


5



SHOULDER STRAPS

Pull the straps to tighten as needed. Control straps and sternal pad should fit securely to anatomy.

6



6A: Control straps configuration for under-the-arm fit.

6B: Control straps configuration for over-the-shoulder fit.

